COIR LOG PLACEMENT

NOTES

- 1. Coir logs shall be installed starting at the bottom of the slope and working uphill.
- 2. Excavated material shall be spread evenly along the uphill slope and compacted by hand tamping or other methods approved by the Engineer.
- 3. Overlap Coir log ends by 12" (in) to prevent water from moving between logs.
- 4. Always install Coir log perpendicular to slope along contour lines. Ends shall angle
- 6. Coir logs shall be in accordance with **Standard Specification**, **Section 9-14.5(7)**, and be installed in accordance with **Standard Specification**, **Section 8-01.3(6)A**.
- 7. Perform maintenance in accordance with Standard Specification, Section 8-01.3(15).

EROSION CONTROL DETAILS COIR LOG PLACEMENT

STANDARD PLAN I-30.60-02

SHEET 1 OF 1 SHEET

APPROVED FOR PUBLICATION

STATE DESIGN ENGINEER